

Release Notes – E370 V1.1b (Production Release) Feb. 8, 2018

To install the software

- a) copy the e370_fm.w.bin file to the ROOT directory of your uSD card. The card MUST BE FAT32 formatted.
- b) turn off power to the E370, insert the uSD card, and while HOLDING DOWN the encoder knob, apply power.
- c) release the knob. The Bootloader should run and detect the firmware file. It will ask if you really want to do this, select YES and click. The new firmware will load.
- d) remove the uSD card when the E370 reboots.

Bug fixes (since V1.0c initial production release):

- 1) Increase A/D sample rate to reduce noise during audio-rate FM when using an external source
- 2) Fixed Wavefolder not reaching 'zero' amount
- 3) Fixed Wavefolder in Cloud+Morph not sharing parameters
- 4) Fixed restricted Z-Morph range in 2-OP FM mode (was not scanning all 64 wavetables)

Bug fixes over V1.1.a production release

- a) Fixes issue with having USR H wavebank in VCO4 while in Waves mode
- b) Fixes issue where the user presets were cleared if the File menu was entered/exited without a uSD card inserted

Notes

- 1) This release does NOT affect any stored user wavetables or presets