

# **This firmware, when installed on your E370, will OVER- WRITE ALL THE PRESETS AND USER WAVETABLES.**

To install the software

- a) copy the e370\_fm.w.bin file to the ROOT directory of your uSD card. The card MUST BE FAT32 formatted.
- b) turn off power to the E370, insert the uSD card, and while HOLDING DOWN the encoder knob, apply power.
- c) release the knob. The Bootloader should run and detect the firmware file. It will ask if you really want to do this, select YES and click. The new firmware will load.
- d) remove the uSD card when the E370 reboots.

Bugfixes:

- \* - Fixed issue that loaded in a preset did not correctly update the CV routing matrix

Features:

- \* - individual SYNC inputs for each VCO can be muted (ignored)

Notes